






Código	Código de la pieza	Nombre
026	170250200	BARRA DENTADA PS3400TH
017	225213060	MUELLE PROTEC.DE MANO
027	913850155	TORNILLO 5X15 PS3400TH
222	923208004	TUERCA HEXAGONAL M-8
023	170213080	CINTA DE FRENO PS3400TH
022	028213521	RESORTE
008	170114100	TAPON ACEITE PS5105
010	170114100	TAPON ACEITE PS5105
012	980114904	
220	170213302	
228	036110021	BULON PS3400TH
021	962650200	PRISIONERO 5X20 PS3400TH
009	963225030	JUNTA TAPON PS3400TH
011	963225030	JUNTA TAPON PS3400TH
002	170111180	CUBIERTA ROJA PS 3400TH
020	028213532	SOPORTE CINTA DE FRENO CPL.
229	980115962	
018	170213040	CUBIERTA PS3400TH
223	170213100	BULON DE RETENCION PS3400TH
003	915735100	TORNILLO 3.5X10 PS3400TH
019	915735100	TORNILLO 3.5X10 PS3400TH
025	915735100	TORNILLO 3.5X10 PS3400TH
224	915735100	TORNILLO 3.5X10 PS3400TH
024	170213050	CUBIERTA PS3400TH
006	170175010	JUEGO VALVULA PS3400TH
001	170111304	
004	170111050	CASQUILLO PS3400TH
005	170111050	CASQUILLO PS3400TH
227	001213042	TUERCA CON ESPIGA DES400
016	810449-4	
007	010245030	VALVULA DE VENTILACION DCS6400
015	170213020	PROTECTOR MANO CPL PS3400TH
225	170111070	CHAPA DE GUIA PS3400TH
013	980114919	
226	036213090	TORNILLO




Código	Código de la pieza	Nombre
061	915735100	TORNILLO 3.5X10 PS3400TH
033	170132020	BULON DE PISTON PS3400TH
031	170132100	PISTON COMPLETO PS3400TH
038	170174100	SILENCIOSO PS3400TH
059	170155050	VARILLAS ESTRANGUL.AIRE
040	170120101	
051	913340204	TORNILLO 4X20
214	170118050	
063	908004406	
041	962211006	JAULA DE AGUJAS PS3400TH
064	170173021	FILTRO AIRE ROBKOFLK DCS410TH
062	170151051	FIJACION DCS3410TH
065	170118100	TAPA FILTRO PS3400TH
058	170118041	GUIA DE AJUSTE DCS3410TH
068	170118031	GUIA DE AJUSTE DCS3410TH
035	266605-8	TORNILLO 5X16 PS32/EA3200
037	170174050	JUNTA ESCAPE PS3400TH
060	170155040	PALANCA ESTRANGUL.AIRE
066	170118020	TORNILLO TAPA FILTRO PS3400TH
042	960102131	RODAMIENTO 6201
043	960102131	RODAMIENTO 6201
067	168398-2	BOMBA DE IGNICION PS220TH
034	170132040	ANILLO ELASTICO PS3400TH
053	170114070	CONDUCTO COMBUSTIBLE PS3400TH
046	170111201	CARTER CIGÜEÑAL PS3400TH
050	170131100	BRIDA INTERMEDIA PS3400TH
049	170131040	JUNTA CARTER PS3400TH
048	908005205	TORNILLO TORX 5X20
036	170174081	CHAPA DEFLECTORA PS3410T
039	908405145	TORNILLO 5X14
030	170131010	CYLINDRO PS3400TH
044	962900060	RETEN 12/32X7
045	962900060	RETEN 12/32X7
213	170118070	
054	163447-0	FILTRO DE GASOLINA PS220TH
032	170132030	SEGMENTO PISTON PS3400TH
052	965524023	JUNTA ADMISION




Código	Código de la pieza	Nombre
080	170245200	CONDUCTO ASPIRACION PS3400TH
085B	170223202	
085D	170223202	
086	900006064	
083	908004125	TORNILLO ESTRELLA M4X12
073	170245030	PALANCA DE REGLAJE DCS3410TH
084C	170181010	EMBRAGUE PS3400TH
084D	170181010	EMBRAGUE PS3400TH
088A	140484-1	
088C	140484-1	
074	170245090	CUBIERTA PS3410TH
075	915735100	TORNILLO 3.5X10 PS3400TH
070	170245101	BOMBA DE ACEITE CPL. PS3400TH
081	231975-4	MUELLE BOMBA ACEITE PS220TH
077A	165180200	
077B	165180200	
082-1	452666-6	PIPA TUBO ACEITE PS32
082	416274-7	TAPA DEL TUBO ACEITE PS220TH
089A	267833-8	
089C	267833-8	
078A	165184020	MUELLE EMBRAGUE PS35
078B	165184020	MUELLE EMBRAGUE PS35
072	170245300	JUEGO DE REPARAR PS3400TH
087	927306000	ARANDELA
079	165182060	
071	170245110	TUBO DE ACEITE PS3400TH
076	170245130	PROPULSOR BOMBA ACEITE DCS3410
085A	170223111	TAMBOR CPL. PS3400TH
085C	170223111	TAMBOR CPL. PS3400TH



Código	Código de la pieza	Nombre
104	913340204	TORNILLO 4X20
130	170143110	BOBINA DE ENCENDIDO DCS3410TH
106	195160080	ARANDELA
129	957166100	TRINQUETE DE ARRANQUE PS3400TH
108	965404840	JUNTA
131	908004165	TORNILLO 4X16 PS3400TH
107	170160760	TIRADOR DE ARRANQUE DCS3410TH
126	920308024	TUERCA M8X1
122	915735100	TORNILLO 3.5X10 PS3400TH
112	170160770	MUELLE
103	980115686	
114	170160790	TORNILLO
109	930216030	ARANDELA DENTADA
127	926208001	ARANDELA DE PRESION 8
102	170160250	DISPOS.DE ARRANQUE CPL.ROJO
128	170141101	VOLANTE DE ENCENDIDO PS3400TH
125	170143031	
105	021164010	CORDON DE ARRANQUE 3X90MM
124	170147010	JUEGO DE CABLES PS3400TH
111	170160740	TAMBOR PARA CORDON DCS3410TH
132	170140100	SET VOLANTE/BOBINA ENCENDIDO
123	168648-5	BUJIA PARA MS3500
110	170160730	MUELLE RETENCION DCS3410TH
120	170160021	
113	170160780	RUEDA DE ARRANQUE DCS3410TH



Código	Código de la pieza	Nombre
188	170111060	TOPE DE CIERRE PS3400TH
175	913650304	TORNILLO 5X30
181	913650304	TORNILLO 5X30
183	913650304	TORNILLO 5X30
172	913340204	TORNILLO 4X20
173	965403491	AMORTIGUADOR
185	965403491	AMORTIGUADOR
182	170310010	MANGO TUBULAR PS3400TH
177	170117030	ACELERADOR PS3400TH
171	170313010	SEMIMANGO DERECHO PS3400TH
178	170117050	MUELLE ACELERADOR PS3400TH
174	170313080	ARO DE RETENCION DCS3410TH
186	170146050	INTERRUPTOR PS3400TH
176	170117040	PALANCA TRINCADA PS3400TH
179	170312011	
184	036114020	CASQUILLO DE AJUSTE PARA DCS34
170	170311010	SEMIMANGO IZQ. PS34000TH
187	170146010	CONECTOR PLANO PS3400TH



Código	Código de la pieza	Nombre
305	021151160	TAPA DE BOMBA
317	021151120	TAPA DE MEMBRANA CARB.WT174
321	001151820	TORNILLO REGUL.(H) DCS3410TH
304	118151190	TORNILLO CARB.WT174
303	170151260	MUELLE
316	957150040	JUEGO AGUJA MANDO CARB.WT174
315	957151070	BOMBA DE ACLERACION DCS3410TH
311	957151060	JUEGO EJE VALVULA REG. DCS3410
310	170151280	MUELLE
309	119151350	PIEZA SEGURIDAD ARBOL PS3410TH
312	119151350	PIEZA SEGURIDAD ARBOL PS3410TH
300	170151100	CARBURADOR CPL PS3410TH
313	001151310	MUELLE CARB.WT174
320	001151810	TORNILLO REGUL.(L) DCS3410TH
306	021151540	JUEGO DE JUNTAS CARB.WT174
307	021151150	MEMBR. BOMBA, CUCHO P/DCS520
314	021151180	TAM 12 CARB.WT174
308	957151040	JUEGO EJE VALVULA AIRE DCS3410
322	021151530	MUELLE DE AGUJA CARB.WT174
302	378151210	TORNILLO DE TOPE DCS3410TH
318	378151220	TORNILLO